

# Blaupunkt oven, combi-steamer & microwave care.

---

## For maintenance we advise:

- If your oven has a self-cleaning feature, follow the instructions in your owner's manual to activate it. Remove all racks and accessories from the oven before self-cleaning.
- For spot cleaning inside the oven, wipe up spills immediately with a damp cloth, use baking soda paste or vinegar for stubborn spots, and avoid harsh chemicals or abrasives.
- For stainless steel surfaces, use mild soapy water and a soft cloth. Do not apply it to logos, control labels or black steel.
- To clean black stainless steel, simply use mild soapy water and a soft cloth.
- Wipe down knobs and other surfaces with a damp cloth.
- Racks should be washed with warm, soapy water and a soft cloth. Do not leave racks in the oven during the self-cleaning program.

---

## Tips the following treatments:

- Regular cleaning: Wipe up spills and crumbs after every use.
- Use oven liners: Place a liner or tray under food to catch drips.
- Avoid harsh chemicals: Stick to safe cleaners or natural solutions like vinegar and baking soda.

# Blaupunkt oven, combi-steamer & microwave care.

---

**Please avoid**  
the following treatments:

- Avoid harsh abrasives (e.g., steel wool) to prevent scratches.
- Avoid spraying cleaners on heating elements to prevent damage and fumes.
- Avoid mixing cleaning chemicals like bleach, chlorine-based cleaners and abrasive cleaners
- Avoid leaving cleaner residue to prevent smoke or odors during use.
- Avoid using the self-clean cycle without ventilation (smoke and fumes).
- Avoid cleaning a hot oven to prevent burns and ineffective cleaning.
- Avoid flammable materials (e.g., paint thinners) to reduce fire risk.
- Avoid ignoring safety gear—wear gloves and ventilate the area.